



EH1662/EH1662EU



**Twin Pack Reusable Silica
Dehumidification Kit with Shoe
Drying Adaptor
User Manual
Notice d'Utilisation**


IMPORTANT

Installer and Users please note:

These instructions should be read carefully and left with the user of the product for future reference.

This product is designed to be used in confined areas such as cupboards, wardrobes and draws. It is not suitable for larger areas.

ASSEMBLY INSTRUCTIONS



Before assembly please inspect the product including its cable and plug for any signs of damage. If the product is damaged, DO NOT use it, and contact your supplier immediately.

OPERATION

- Plug the mains lead into a 13 Amp mains socket. If any other appliances are connected to the same extension lead, make sure that it is rated for the total power of all appliances connected.
- If connecting via an extension lead, make sure that the lead is rated at 3 Amps or more, and that it is fully unwound.
- Take the first dehumidifying unit and attach it to the base unit. Make sure it is in place before letting go.
- Switch the appliance on at the mains socket. The unit is charged when the crystals turn orange. This should take approx. 2-3 hours per unit.
- Remove the dehumidifier from the base. It is now ready to use. Repeat the operation on the second dehumidifier.
- Place the charged dehumidifier in the required area.
- For drying shoes, add the shoe drying adaptor to the top of the base unit and place the vents in the shoe opening making sure the base is stable at all times.
- It is normal for the dehumidifier to become slightly warm in normal use.
- Unplug the appliance base unit from the mains when not in use.

OPERATING COSTS

At time of going to press, the average cost of electricity is £0.12 per unit (kilowatt-hour). The amount you are being charged will be shown on your electricity bill. At this cost, the EH1662 will cost 0.01p per hour to run as a shoe dryer and will cost approx. 3p to charge a dehumidifier cartridge.

PAT TESTING

When used in an office environment, we recommend that this product should be safety-tested yearly by a qualified electrician (PAT Tested).

We recommend that it is PAT tested regularly when used in a domestic environment.

GENERAL SAFETY REQUIREMENTS

Domestic wiring must be tested periodically by a qualified electrician at least once every 10 years or at every change of occupancy.

For office and retail premises, and buildings such as village halls, the wiring must be inspected at least once every 5 years.

It is recommended that all building be fitted with smoke alarms (it is mandatory for new buildings).

DISPOSAL AND RECYCLING

You must not dispose of this appliance with domestic household waste.

Most local authorities have specific collection system for appliances and disposal is free of charge to the end-user.

When replacing an existing appliance with a similar new appliance your retailer may take the old appliance for disposal.

PRODUCT SAFETY

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- When attached to the base unit the appliance must be placed on a firm flat surface.
- Do not use in close proximity to gas appliances
- Do not use unless correctly installed.
Do not cover when in use.
- Do not place the mains lead beneath a carpet or rug.
- Do not use the appliance in locations where paint, petrol or other flammable liquids are used or stored.
- Do not insert any object into the appliance through the grilles. This may damage the appliance or result in overheating or electric shock.
- Do not use this appliance in the immediate surroundings of a bath, a shower or a swimming pool.
- This appliance is fitted with a thermal fuse.
- Do not use the dehumidifier in a confined space while attached to the base unit.


MAINTENANCE

Before cleaning, turn the appliance off, and disconnect from the mains supply. The appliance may then be cleaned using a damp cloth with a drop of washing-up liquid to remove any dust or dirt from the case. Do not use stronger detergents or solvents as these may damage the plastic.

Using a dry 1" (25 mm) paint-brush, remove any dust from the vents

If the mains lead is damaged, it must be replaced by the manufacturer or an authorised service centre.

If the mains plug needs to be replaced, proceed as follows:



- Connect the brown wire to the terminal labelled "L".
- Connect the blue wire to the terminal labelled "N".
If the plug is fitted with a 13 A fuse, replace it with a 3 A fuse.
- Make sure that the cord-grip is positioned correctly (over the outer sheath of the cable) and it fully tightened.

TECHNICAL SPECIFICATION

Dimensions:	190x275x105 mm
Weight:	1.45 kg
Power supply:	230 V ~
Power Consumption	75 W
Dehumidifiers Type:	Silica beads

SERVICE WARRANTY

Prem-i-Air guarantees the product free from defects in materials and workmanship for a period of twelve months.

Should this appliance be operated under conditions other than those recommended, at voltages other than the voltage indicated on the appliance, or any attempts made to service or modify the appliance, then the warranty will be rendered void.

The product you buy may sometimes differ slightly from illustrations. This warranty is in addition to, and does not affect, your statutory rights.

Our guarantee is administered by our retailers.

If your product arrives damaged, you must contact the retailer from whom you bought it. The retailer's contact details will be on the invoice that arrived with the product, or on the e-mail you received when you placed the order. Do not contact Prem-i-air, only your retailer can arrange a replacement.

If your product fails within the guarantee period, firstly read the "fault finding" section of this manual, because temperature and weather conditions can affect the performance of certain products. If the product needs to be repaired or replaced, you must contact the retailer from whom you bought it.

The retailer's contact details will be on the invoice that arrived with the product, or on the e-mail you received when you placed the order.

If you have just received your product and require technical help in using it, please call our Help Desk on (0845) 459 4816

If you have any other technical queries about the product, please call our Help Desk on (0845) 459 4816.

Prem-i-Air Appliances Ltd.,
Lancots Lane, Sutton,
St. Helens, Merseyside.
WA9 3EX

www.prem-i-air.com